


# HDMI over CAT6/6A Extender - 4K 60Hz - 230ft (70m)

### **Product ID**

4K70IC-EXTEND-HDMI

#### Transmitter



Port		Function
1	Reset Button	Transmitter and Receiver: Reboots the unit which will cause a renegotiation of connected devices
2	RJ45 Port	Connect the <b>Transmitter</b> and <b>Receiver</b> together, using a <b>CAT6/6a Ethernet Cable</b> (sold separately)
3	Power Indicator	<ul> <li>Flashing Blue: Power connected, but no HDMI input signal is detected</li> <li>Solid Blue: Power connected, and a HDMI input signal is detected</li> </ul>
4	DC 12V Port	Power the <b>Transmitter</b> or <b>Receiver</b> using the included <b>Power Adapter</b>
5	HDMI Output Port	Connect to an HDMI Display
6	HDMI Input Port	Connect to an HDMI Source Device
7	IR Output Port	Connect the IR Blaster to the Transmitter
8	Audio Input Selector	Switch Receiver's audio input source between the Transmitter's HDMI Input Port, or Receiver's HDMI Output Port
9	Optical Audio Output	Connect to an S/PDIF Input on a Audio Device (i.e. A/V Receiver)
10	IR Input Port	Connect the IR Receiver to the Receiver

### **Product Information**

For the latest product information, technical specifications, and declarations of conformance, please visit: <a href="https://www.StarTech.com/4K70IC-EXTEND-HDM">www.StarTech.com/4K70IC-EXTEND-HDM</a>I

## **Package Contents**

- Local HDMI Transmitter Unit x 1
- Remote HDMI Receiver Unit x 1
- IR Blaster x 1
- IR Receiver x 1
- Rubber Feet x 8
- Mounting Kit x 1
- Power Adapter x 1
- · Quick-Start Guide x 1

### Installation

### (Optional) Mounting Kit

**Note:** Before mounting the **HDMI Extender** make sure that the surface you are mounting to is strong enough to support the weight of the **HDMI Extender**. It is recommended that you mount the **HDMI Extender** on a wall stud to provide the correct support.

- 1. Determine the **Mounting Surface** for the **HDMI Extender**.
- Place the Mounting Brackets on each side of the HDMI Extender. Align the Holes in the Mounting Brackets with the Holes on the sides of the HDMI Extender's Transmitter and Receiver.
- 3. Insert two **Screws** through each **Mounting Bracket** and into the **HDMI Extender**.
- 4. Tighten each **Screw** using a **Phillips Head Screwdriver**.
- 5. Mount the **HDMI Extender** to the desired **Mounting Surface** using the appropriate **Mounting Hardware** (e.g. Wood Screws).

## Installing the HDMI Transmitter and Receiver

- On the Transmitter, use the Audio Output Selector to set which audio output the setup requires.
  - **Note:** If changing the audio output after initial installation, a power cycle may be required.
- 2. Position the **Transmitter** near the **HDMI Source Device**.
- Connect an HDMI Cable (not included) from the HDMI Source Device to the HDMI Input Port on the Transmitter.
- 4. (Optional) Connect an **HDMI Cable** (not included) from the **HDMI Output Port** on the **Transmitter**, to a **Local HDMI Display**.

- 5. Position the HDMI Receiver near the HDMI Display Device.
- Connect a CAT5e/6 Cable (not included) from the RJ45 Port on the Transmitter to the RJ45 Port on the Receiver.

**Note:** The cabling cannot go through any networking equipment (e.g. router, switch, etc.).

- Connect an HDMI Cable (not included) to the HDMI Output Port on the Receiver and to the HDMI Display Device.
- 8. (Optional) Connect a **Toslink (S/PDIF) Cable** from the **Optical Audio Output** on the **Receiver**, to a **Optical Audio Input** on an **Audio Device** (i.e. A/V Receiver)
- Connect the included Universal Power Adapter to the DC 12V Port on the Transmitter or Receiver and to an Electrical Outlet.

**Note:** For optimal performance, it is recommended to power the **HDMI Extender Kit** through the **Transmitter** unit. However, it is possible to power the **HDMI Extender Kit** through the **Receiver** unit by connecting the **Universal Power Adapter** to the **Receiver** unit.

### Installing the IR Blaster and IR Receiver

Control the HDMI Source Device from the Receiver's location

- 1. Connect the IR Blaster (Labelled "IR Out") to the IR Output Port on the Transmitter.
- 2. Peel the **Film** off of the **Adhesive Pad** that is located on the **IR Blaster**. Position the **IR Blaster** so that it is pointing directly at the **IR Sensor** on the **HDMI Source Device**. **Note:** Consult the **HDMI Source Device**'s manual to determine the location of the **IR**
- 3. Connect the IR Receiver (Labelled "IR In") to the IR Input Port on the Receiver.
- Peel the Film off of the Adhesive Pad that is located on the IR Receiver. Position the IR Receiver in a location where there is a clear path to the Remote Control.
- 5. Use the **Remote Control** for the **HDMI Source Device** to control the **HDMI Source Device** from the **Receiver's** location.

# Regulatory Compliance FCC - Part 15

Sensor.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

#### **Industry Canada Statement**

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## **Operation**


### **Audio Input Selector**

The **Audio Input Selector Switch** can be used to change which **Audio Source** is used for the **Receiver** unit, depending on the requirements of the setup.

**Note:** Audio will output through the **S/PDIF Port** in both modes. For **ARC Mode**, **HDMI Audio Return Channel** support is required on the **HDMI Display**.

Audio Input Selector Mode	Receiver Audio Source
S/PDIF	HDMI Audio from Transmitter – Audio of the HDMI Source is output.
ARC	HDMI Audio from the display on the receiver side is output.

## **Connection Diagram**



# Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

### **Warranty Information**

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

### **Limitation of Liability**

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

StarTech.com Ltd. 45 Artisans Cres London, Ontario N5V 5E9 Canada StarTech.com LLP 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.

StarTech.com Ltd.
Unit B, Pinnacle 15
Gowerton Rd,
Brackmills
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd. Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands FR: startech.com/fr DE: startech.com/de ES: startech.com/es NL: startech.com/nl IT: startech.com/ip